



























































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Info	 +  Shift + Info	Menu Down	 Down
App	 Media	Back	 Back
Opt?	 Options	Audio	 Dual
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7



Original	Replacement	
8tuv	 8	
9wxyz	 9	
Guide Pilote	 Guide	
0/10	 0	
FAV Pref.	 Pre Ch	
Red	 Red	
Green	 Green	
Yellow	 Yellow	
Blue	 Blue	
Dev	 List	
On/Off	 +  Shift + Power	
	 +  Shift + Mute	
West	 +  Shift + I<<	
+	 +  Shift + Subt	
Freeze	 Stop	
Dec/Pause	 Pause	
Sys/Serv	 +  Shift + Sleep	

Original	Replacement	
Scan/Setup	 +  Shift + TV/R	
SAT Sky	 Smart	
	 +  Shift + Vol +	
	 >>I	
	 +  Shift + Vol -	
Home Cinema	 +  Shift + Media	
East	 +  Shift + Red	
	 I<<	
Lang./Rewind	 <<	
H/V Play	 Play	
LNB F.Forward	 >>	

