















































































	Original	Replacement		Original	Replacement
	 Standby	 Power		 Freeze	 Pause
	 Info	 Info		 TV/Radio	 TV/R
	 Mute	 Mute		 FAV	 Pre Ch
	 P.Mode	 Format		 Source	 AV
	 S.Mode	 Dual		 Recall	 Back
	 Zoom	 Shift + Eject		 CH List	 List
	 Sleep	 Sleep		 Up	 Up
	 1	 1		 Left	 Left
	 2	 2		 OK	 Ok
	 3	 3		 Right	 Right
	 4	 4		 Down	 Down
	 5	 5		 Vol+	 Vol +
	 6	 6		 Vol-	 Vol -
	 7	 7		 CH+	 Ch +
	 8	 8		 CH-	 Ch -
	 9	 9		 LCD Menu	 Menu
	 0	 0		 EPG / DVD	 Guide



Menu



Original	Replacement
 EPG / DVD	 D. Menu
 Audio	 Shift + Dual
 Exit / DVD Setup	 Exit
 Exit / DVD Setup	 Options
 TXT	 Text
 Index / Angle	 Smart
 Size	 3D
 Subtitle	 Subt
 Mix / Open/Close	 Shift + Text
 Mix / Open/Close	 Eject
 Play/Pause /	 Play
 Stop / Hold	 Stop
 A-B / Subpage	 Media
 << / Red	 Red
 << / Red	 <<
 >> / Green	 >>
 >> / Green	 Green

Original	Replacement
 I<< / Yellow	 I<<
 I<< / Yellow	 Yellow
 >>I / Blue	 >>I
 >>I / Blue	 Blue

