







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	F1		Shift + 1
	DVB		D. Menu
	Android		List
	TXT		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	<X		Exit
	Recall		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mouse		Media
	Home		Smart
	P+		Ch +
	P-		Ch -
	EPG		Guide
	Info		Info
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Menu		Menu
	Back		Back
	Red		Red





Original	Replacement	Original	Replacement
	Green		Green
	Yellow		Yellow
	Blue		Blue
	FAV	 + 	Shift + Pre Ch
	Subt		Subt
	Audio		Dual
	TV/Ra		TV/R
	Rec		Rec
	SAT		AV
	Play/Pause		Play
	Play/Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>

