

























































Original	Replacement
 Power	 Power
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 10+	 Guide
 Goto	 Pre Ch
 FF+	 Blue
 FF-	 Yellow
 Prog	 Sleep

Original	Replacement
 Memory	 Rec
 CH+	 Ch +
 CH-	 Ch -
 >>I	 >>I
 I<<	 I<<
 >>	 >>
 <<	 <<
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Repeat	 Text
 A-B	 D. Menu
 Source	 AV
 CD/USB	 Media
 Treble+	 Up
 Treble-	 Down
 Bass+	 Right





Original		Replacement		Original		Replacement	
	Bass-		Left				
	Random		Smart				
	Search		TV/R				
	Intro		Ok				
	EQ		Format				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	Loudness		3D				
	A1		Red				
	A2		Green				

