































































Original		Replacement		Original		Replacement	
	Power		Power		5		5
	Menu		Menu / Home		6		6
	Up		Up		7		7
	Left		Left		8		8
	OK		OK		9		9
	Right		Right		0		0
	Down		Down		<<		Shift + << /
	Back		Back / Return		<<		<< / Tune-
	Vol+		Vol+		Play / Pause		Shift + Play /
	CH+		CH+ / Page+		Play / Pause		Play / Slow
	Vol- / Mute		Shift + Vol+		>>		Shift + >> /
	Vol- / Mute		Vol-		>>		>> / Tune+
	CH-		CH- / Page-		Rec / Stop Rec		Rec / Rec Mode
	1		1				
	2		2				
	3		3				
	4		4				

