






































































Original	Replacement
 Power	 Power
 Power Tv	 Shift + Power
 Vol+ Tv	 Vol+
 CH+ TV	 Shift + CH+ /
 AV Input Tv	 AV / Input / RDS
 Vol- Tv	 Vol-
 CH- Tv	 Shift + CH- /
 1	 1
 2	 2
 3	 3
 Rec	 Rec / Rec Mode
 4	 4
 5	 5
 6	 6
 CH+	 CH+ / Page+
 7	 7
 8	 8

Original	Replacement
 9	 9
 CH-	 CH- / Page-
 Last View	 Shift + Back / Return
 0	 0
 Drive Select	 Display / Media
 Prog/Check	 Menu / Home
 -10s	 Fav / Marker / PC
 +60s	 Shift + Guide / EPG / -/-
 Internet	 Smart / List
 Netflix	 Shift + Red / Netflix /
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 Stop	 Stop / Hold





Original	Replacement
i/Status	Info / Angle
Guide	Guide / EPG / -/--
Exit	Exit / Cancel / Clear
Video Menu	Shift + 4
Up	Up
Function Menu	D.Menu / Top
Left	Left
OK	OK
Right	Right
Option	Setup / OPT /
Down	Down
Return	Back / Return
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Audio	Audio / Lang I/II

Original	Replacement
Delete	Shift + Exit / Cancel / Clear
Text	Text / Goto
STTL	Subtitle / EQ

