







































































Original		Replacement		Original		Replacement	
	Power		Power		Yellow		Yellow
	Input		AV		Blue		Blue
	1		1		[=]		Menu
	2		2		Pause		Pause
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Back		Back
	9		9		Exit		Exit
	0		0		Vol+		Vol +
	Guide		Guide		Vol-		Vol -
	CH.List		List		Home		Smart
	Play		Play		Micro		Media
	Red		Red		CH+		Ch +
	Green		Green		CH-		Ch -





Original		Replacement	
	Subtitle		Subt
	Mute		Mute
	Text		Text
	Free		Options
	Sports		TV/R
	Chili		Dual
	Netflix		Shift + Media
	prime video		3D
	YouTube		Pre Ch
	TV Timvision		Shift + TV/R
	Rakuten Tv		D. Menu
	Rai Play		Shift + Smart

Original		Replacement	

