






































































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 PIP	 Info / Angle
 4	 4
 5	 5
 6	 6
 [<>]	 Picture / Format
 >	 >> / Preset+
 7	 7
 8	 8
 9	 9
 ?	 Smart / List
 <	 << / Preset-
 0	 0
 Mute	 Mute / Dimmer

Original	Replacement
 i/OSD	 Display / Media
 Z/Disc Menu	 Menu / Home
 Up	 Up
 P+	 CH+ / Page+
 Left	 Left
 Vol-	 Vol-
 OK	 OK
 Right	 Right
 Vol+	 Vol+
 TXT	 Text / Goto
 <<	 << / Tune-
 Down	 Down
 P-	 CH- / Page-
 TV-G	 Guide / EPG / -/-
 >>	 >> / Tune+
 Red/Image/I>	 Red / Netflix / Search
 Green/Timer	 Green / APP / Repeat























































Original		Replacement		Original		Replacement	
	Play		Play / Slow				
	Yellow/Pause		Yellow / YouTube / Repeat				
	Pause		Pause / Step / Freeze				
	Blue/Sound		Blue / Prime Video / Random				
	Stop		Stop / Hold				
	Blue/Sound		Sound / Title				





















Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 Audio	 Audio / Lang I/II
 4	 4
 5	 5
 6	 6
 [<>]	 Zoom / Size
 >	 >> / Preset+
 7	 7
 8	 8
 9	 9
 ?	 Smart / List
 <	 << / Preset-
 0	 0
 i/OSD	 Display / Media

Original	Replacement
 Disc Menu	 D.Menu / Top
 Disc Menu	 Menu / Home
 Up	 Up
 P+	 CH+ / Page+
 Left	 Left
 Vol-	 Vol-
 OK	 OK
 Right	 Right
 Vol+	 Vol+
 TXT	 Text / Goto
 <<	 << / Tune-
 Down	 Down
 P-	 CH- / Page-
 TV-G	 Guide / EPG / -/-
 >>	 >> / Tune+
 Red/Picture	 Picture / Format
 Red/Picture	 Red / Netflix / Search





Original	Replacement	Original	Replacement
 Green / Timer	 Sleep / Timer		
 Play	 Play / Slow		
 Green / Timer	 Green / APP / Repeat		
 Yellow/Pause	 Yellow / YouTube / Repeat		
 Pause	 Pause / Step / Freeze		
 Blue/Sound	 Sound / Title		
 Stop	 Stop / Hold		
 Blue/Sound	 Blue / Prime Video / Random		





















Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>		>> / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	<		<< / Preset-
	0		0
	Mute		Mute / Dimmer
	i/OSD		Display / Media
	Z/Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol-		Vol-
	OK		OK
	Right		Right
	Vol+		Vol+
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/-
	>>		>> / Tune+
	Red/Image/I>		Red / Netflix / Search
	Red/Image/I>		Shift +
			Play / Slow



































Original	Replacement	Original	Replacement
	 Green / APP / Repeat		
	 Play / Slow		
	 Sleep / Timer		
	 Pause / Step / Freeze		
	 Yellow / YouTube / Repeat		
	 Blue / Prime Video / Random		
	 Stop / Hold		
	 Sound / Title		





Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 PIP/Audio	 Audio / Lang I/II
 4	 4
 5	 5
 6	 6
 [<>]	 Zoom / Size
 7	 7
 8	 8
 9	 9
 ?	 Smart / List
 <	 << / Preset-
 >	 >> / Preset+
 0	 0
 i/OSD	 Display / Media

Original	Replacement
 Z/Disc Menu	 Menu / Home
 P+	 CH+ / Page+
 Up	 Up
 Left	 Left
 Vol-	 Vol-
 OK	 OK
 Right	 Right
 Vol+	 Vol+
 TXT	 Text / Goto
 <<	 << / Tune-
 P-	 CH- / Page-
 Down	 Down
 TV-G	 Guide / EPG / -/-
 >>	 >> / Tune+
 Red/Image/I>	 Picture / Format
 Red/Image/I>	 Red / Netflix / Search
 Green/Timer	 Green / APP / Repeat





Original	Replacement	Original	Replacement
	Play / Slow		
	Sleep / Timer		
	Yellow / YouTube / Repeat		
	Pause / Step / Freeze		
	Blue / Prime Video / Random		
	Stop / Hold		
	Sound / Title		

