







































































| Original | | Replacement | | Original | | Replacement | |
|---|---------|---|------------------|---|-------------------|---|-----------------------|
|  | Power |  | Power |  | 7 |  | 7 |
|  | Mute |  | Mute / Dimmer |  | 8 |  | 8 |
|  | Vol- |  | Vol- |  | 9 |  | 9 |
|  | Vol+ |  | Vol+ |  | 0 |  | 0 |
|  | P- |  | CH- / Page- |  | -/-- |  | Guide / EPG / -/-- |
|  | P+ |  | CH+ / Page+ |  | Contrast- |  | I<< / Preset- |
|  | Power 2 |  | Shift + Power |  | Contrast+ |  | >>I / Preset+ |
|  | [+] |  | Display / Media |  | Brightness- |  | Down |
|  | PP |  | Back / Return |  | Brightness+ |  | Up |
|  | [] |  | Info / Angle |  | Text |  | Text / Goto |
|  | []↔ |  | Picture / Format |  | Text Subcode |  | Subtitle / EQ |
|  | 1 |  | 1 |  | Text Hold |  | Shift + Stop / |
|  | 2 |  | 2 |  | Text Size |  | Zoom / Size |
|  | 3 |  | 3 |  | Text Reveal |  | Smart / List |
|  | 4 |  | 4 |  | Text Index / Play |  | Play / Slow |
|  | 5 |  | 5 |  | Text Mix |  | Shift + Text / |
|  | 6 |  | 6 |  | Text Cancel |  | Exit / Cancel / Clear |





| Original | Replacement | Original | Replacement |
|----------|-----------------------------|----------|-------------|
| | Red / Netflix / Search | | |
| | Red / Rec / Rec Mode | | |
| | Green / APP / Repeat | | |
| | Green / Stop / Hold | | |
| | Yellow / YouTube / Repeat | | |
| | Yellow / << / << / Tune- | | |
| | Blue / Prime Video / Random | | |
| | Blue / >> / >> / Tune+ | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Original | | Replacement | | Original | | Replacement | |
|----------|---------|-------------|------------------|--------------|--------------|-------------|-----------------------|
| | Power | | Power | | 7 | | 7 |
| | Mute | | Mute / Dimmer | | 8 | | 8 |
| | Vol- | | Vol- | | 9 | | 9 |
| | Vol+ | | Vol+ | | 0 | | 0 |
| | P- | | CH- / Page- | | -/-- | | Guide / EPG / -/-- |
| | P+ | | CH+ / Page+ | | Text | | Text / Goto |
| | Power 2 | | Shift + Power | | Text Subcode | | Subtitle / EQ |
| | [+] | | Display / Media | | Text Hold | | Shift + Stop / |
| | PP | | Back / Return | | Text Size | | Zoom / Size |
| | [] | | Info / Angle | | Text Reveal | | Smart / List |
| | []↔ | | Picture / Format | | Play | | Play / Slow |
| | 1 | | 1 | | Text Mix | | Shift + Text / |
| | 2 | | 2 | | Text Cancel | | Exit / Cancel / Clear |
| | 3 | | 3 | | Rec | | Rec / Rec Mode |
| | 4 | | 4 | | Stop | | Stop / Hold |
| | 5 | | 5 | << button"/> | << | | << / Tune- |
| | 6 | | 6 | >> button"/> | >> | | >> / Tune+ |

