



Original	Replacement
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P	GUIDE EPG / -/--
C	Yellow / YouTube / Repeat
TRACK >I	PRESET+ >>I / Preset+
I< TRACK	PRESET- I<< / Preset-
REVIEW	BACK / Return
PAUSE	STEP-FREEZE Pause / Step / Freeze
STOP	HOLD Stop / Hold

Original	Replacement
PLAY	Play / Slow
FAST	Picture / Format
FTS	Zoom / Size
ARCH >>	>> / Tune+
SEARCH <<	<< / Tune-
INDEX+	CH+ / Page+
INDEX-	CH- / Page-
SHUFFLE	Blue / Prime Video / Random
SCAN	Smart / List
VOLUME+	Vol+
VOLUME-	Vol-
REPEAT	Green / APP / Repeat
TIME	Sleep / Timer
A>B	TV/Radio /
DISPLAY OFF	Power

