






































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Recall		Back / Return
	0		0
	SAT		Shift + 0
	SAT		AV / Input / RDS
	TV/Radio		TV/Radio /
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Live		Display / Media
	VOD		Smart / List
	Series		Shift + Display / Media
	WEB TV		Shift + Smart / List
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	EPG		Guide / EPG / -/--
	Down		Down
	Info		Info / Angle
	Vol+		Vol+
	Fav		Fav / Marker / PC
	Page+		CH+ / Page+





Original		Replacement		Original		Replacement	
	Vol-		Vol-		Stop		Stop / Hold
	Mute		Mute / Dimmer		Rec		Rec / Rec Mode
	Page-		CH- / Page-				
	Red / F1		Red / Netflix / Search				
	Green / F2		Green / APP / Repeat				
	Yellow / F3		Yellow / YouTube / Repeat				
	Blue / IPTV		Blue / Prime Video / Random				
	Option		Setup / OPT /				
	V-Format		Picture / Format				
	Resolution		Zoom / Size				
	Sleep		Sleep / Timer				
	<<		<< / Tune-				
	>>		>> / Tune+				
	I<<		I<< / Preset-				
	>>I		>>I / Preset+				
	Play		Play / Slow				
	Pause		Pause / Step / Freeze				

