











































































































































Original	Replacement	Original	Replacement
 Power	 Power	 OK	 OK
 Red	 Red / Netflix / Search	 Play	 Play / Slow
 Green	 Green / APP / Repeat	 Stop	 Stop / Hold
 Yellow	 Yellow / YouTube / Repeat	 Direct Tv Rec	 TV/Radio /
 Blue	 Blue / Prime Video / Random	 >>	 >> / Tune+
 Cancel	 Shift + Exit / Cancel / Clear	 <<	 << / Tune-
 VPS/PDC	 Fav / Marker / PC	 Exit	 Exit / Cancel / Clear
 Right VPS/PDC	 Subtitle / EQ	 Menu	 Menu / Home
 AV Link	 Display / Media	 1	 1
 Timer Rec	 Zoom / Size	 2	 2
 Right Av Link	 Picture / Format	 3	 3
 OSD/Display	 Info / Angle	 4	 4
 Reset	 Setup / OPT /	 5	 5
 Up	 Up	 6	 6
 Down	 Down	 7	 7
 Right	 Right	 8	 8
 Left	 Left	 9	 9









































Original		Replacement		Original		Replacement	
	Power		Power		Reset		Setup / OPT /
	Prog/Check Up		Shift + Up		Direct Tv Rec		TV/Radio /
	Prog/Check		Shift + Down		Up		Up
	Date+		Shift + CH+ /		Down		Down
	Date-		Shift + CH- /		Right		Right
	On+		Sleep / Timer		Left		Left
	On-		Text / Goto		OK		OK
	Off+		Yellow / YouTube / Repeat		Play		Play / Slow
	Off-		Blue / Prime Video / Random		Stop		Stop / Hold
	Prog/Check		Guide / EPG / -/--		>>		>> / Tune+
	Cancel		Shift + Exit / Cancel / Clear		<<		<< / Tune-
	VPS/PDC		Fav / Marker / PC		Exit		Exit / Cancel / Clear
	Right VPS/PDC		Subtitle / EQ		Menu		Menu / Home
	Timer Rec		Zoom / Size		Show View		Audio / Lang I/II
	AV Link		Display / Media		1		1
	Right Av Link		Picture / Format		2		2
	OSD/Display		Info / Angle		3		3





	Original	Replacement		Original	Replacement
	4	 4		Vol-	 Vol-
	5	 5			
	6	 6			
	7	 7			
	8	 8			
	9	 9			
	0	 0			
	-/--	 Shift + Guide / EPG / -/--			
	Tracking/V-Look+	 CH+ / Page+			
	Tracking/V-Look-	 CH- / Page-			
	AV/Input Select	 AV / Input / RDS			
	Pause/Slow	 Pause / Step / Freeze			
	Rec	 Rec / Rec Mode			
	Search	 Red / Netflix / Search			
	I<< Index	 I<< / Preset-			
	>>I Index	 >>I / Preset+			
	Vol+	 Vol+			

