























































Original	Replacement	Original	Replacement
 Stby	 Power	 >>	 >> / Tune+
 1	 1	 A/B	 Yellow / YouTube / Repeat
 2	 2	 Shuf	 Blue / Prime Video / Random
 3	 3	 I<	 I<< / Preset-
 4	 4	 >I	 >>I / Preset+
 5	 5	 Rep	 Green / APP / Repeat
 6	 6	 Pause	 Pause / Step / Freeze
 7	 7	 Stop	 Stop / Hold
 8	 8	 Play	 Play / Slow
 9	 9		
 0	 0		
 Disc	 Eject / Surround		
 Scan	 Smart / List		
 Prog	 TV/Radio /		
 Time	 Sleep / Timer		
 Fast	 Display / Media		
 <<	 << / Tune-		

