






































































Original	Replacement
 Open / Close	 Eject / Surround
 Power	 Power
 TV Input	 AV / Input / RDS
 Sleep	 Sleep / Timer
 Display	 Shift + Display / Media
 Function+	 CH+ / Page+
 Video Format	 Shift + Picture / Format
 Movie / Music	 Sound / Title
 Dynamic Bass	 Shift + Sound / Title
 Function-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7

Original	Replacement
 8	 8
 9	 9
 Clear	 Exit / Cancel / Clear
 0	 0
 Enter	 Fav / Marker / PC
 Picture Navi	 Picture / Format
 Audio	 Audio / Lang I/II
 Subtitle /	 Subtitle / EQ
 Angle	 Info / Angle
 DVD Top Menu	 D.Menu / Top
 Up	 Up
 DVD Menu	 Menu / Home
 Left	 Left
 OK	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down





Original		Replacement		Original	Replacement
	System Menu		Smart / List		
	[ -]Display		Display / Media		
	I << / Preset-		I << / Preset-		
	Replay		Shift + Left		
	Advance		Shift + Right		
	>>I / Preset+		>>I / Preset+		
	<I / <<< / Tuning-		<<< / Tune-		
	Play		Play / Slow		
	>>> / I> / Tuning+		>>> / Tune+		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		
	Volume+		Vol+		
	Sound Field+		Shift + Vol+		
	Muting		Mute / Dimmer		
	Volume-		Vol-		
	Sound Field-		Shift + Vol-		

