



Original		Replacement		Original		Replacement	
	AVR Power On		Power		3		3
	AVR Power Off		Shift + Power		4		4
	Cable/Sat		Shift + 0		5		5
	Disc		Shift + 2		6		6
	DVR		Shift + 3		7		7
	Radio		Shift + 6		8		8
	Tv		Shift + 1		9		9
	USB		Shift + 8		Last		Back / Return
	Game		Shift + 4		0		0
	Media Server		Shift + 9		Back/Exit		Exit / Cancel / Clear
	Network		Shift + 5		Up		Up
	AUX		Shift + 7		Menu		Menu / Home
	Audio Effects		Audio / Lang I/II		Left		Left
	Video Modes		Picture / Format		OK		OK
	Surround Modes		Eject / Surround		Right		Right
	1		1		Down		Down
	2		2		Red		Red / Netflix / Search









Original	Replacement
Disc Power On	Power
Disc Power Off	Shift + Power
Disc	Display / Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Last	Back / Return
0	0
Back/Exit	Exit / Cancel / Clear
Up	Up
Menu	Menu / Home

Original	Replacement
Left	Left
OK	OK
Right	Right
Down	Down
Disc Menu	D.Menu / Top
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Vol+	Vol+
Mute	Mute / Dimmer
Vol-	Vol-
I<<	I<< / Preset-
Pause	Pause / Step / Freeze
>>I	>>I / Preset+
<<	<< / Tune-
Play	Play / Slow



















Original	Replacement
 DVR Power On	 Power
 DVR	 Display / Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Up	 Up
 Menu	 Menu / Home
 Left	 Left
 Right	 Right
 Down	 Down

Original	Replacement
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH/Page Up	 CH+ / Page+
 Vol-	 Vol-
 CH/Page Down	 CH- / Page-





Original		Replacement		Original		Replacement	
	AVR Power On		Power		3		3
	AVR Power Off		Shift + Power		4		4
	Cable/SAT		Shift + 0		5		5
	Disc		Shift + 2		6		6
	DVR		Shift + 3		7		7
	Radio		Shift + 6		8		8
	TV		Shift + 1		9		9
	USB		Shift + 8		Last		Back / Return
	Game		Shift + 4		0		0
	Media Server		Shift + 9		Back/Exit		Exit / Cancel / Clear
	Network		Shift + 5		Up		Up
	AUX		Shift + 7		Menu		Menu / Home
	Audio Effects		Audio / Lang I/II		Left		Left
	Video Modes		Picture / Format		OK		OK
	Surround Modes		Eject / Surround		Right		Right
	1		1		Down		Down
	2		2		Red		Red / Netflix / Search





