





































Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause / Step / Freeze
 Mute	 Mute / Dimmer	 EPG	 Guide / EPG / -/-
 1	 1	 Up/PR+	 Up
 2	 2	 Menu	 Menu / Home
 3	 3	 Left	 Left
 Tv/Radio	 TV/Radio /	 Vol-	 Vol-
 4	 4	 OK/List	 OK
 5	 5	 Right	 Right
 6	 6	 Vol+	 Vol+
 ↑	 CH+ / Page+	 Info	 Info / Angle
 7	 7	 Down/PR-	 Down
 8	 8	 Exit	 Exit / Cancel / Clear
 9	 9	 [+]	 Zoom / Size
 ↓	 CH- / Page-	 FAV	 Fav / Marker / PC
 0	 0	 Record	 Rec / Rec Mode
 ←PR	 Back / Return	 Stop	 Stop / Hold
 PAL/NTSC	 Picture / Format	 Audio	 Audio / Lang I/II

Original	Replacement	Original	Replacement
 Pause	 Pause / Step / Freeze	 EPG	 Guide / EPG / -/-
 Up/PR+	 Up	 Menu	 Menu / Home
 Left	 Left	 Vol-	 Vol-
 OK/List	 OK	 Right	 Right
 Vol+	 Vol+	 Info	 Info / Angle
 Down/PR-	 Down	 Exit	 Exit / Cancel / Clear
 [+]	 Zoom / Size	 FAV	 Fav / Marker / PC
 Record	 Rec / Rec Mode	 Stop	 Stop / Hold
 Audio	 Audio / Lang I/II		





Original	Replacement	Original	Replacement
 TXT	 Text / Goto		
 Subtitle	 Subtitle / EQ		
 Audio L/R	 Sound / Title		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

Original	Replacement	Original	Replacement

