






































































Original	Replacement	Original	Replacement
 Power	 Power	 MTS	 D.Menu / Top
 Mute	 Mute / Dimmer	 Menu	 Menu / Home
 1	 1	 Up	 Up
 2	 2	 Source	 AV / Input / RDS
 3	 3	 Left	 Left
 4	 4	 Enter	 OK
 5	 5	 Right	 Right
 6	 6	 Exit	 Exit / Cancel / Clear
 7	 7	 Down	 Down
 8	 8	 Display	 Display / Media
 9	 9	 Vol+	 Vol+
 0	 0	 Rec	 Rec / Rec Mode
 ATV/DTV	 Guide / EPG / -/--	 Rec List	 Shift + Rec / Rec Mode
 Recall	 Back / Return	 CH+	 CH+ / Page+
 P.Mode	 Picture / Format	 Vol-	 Vol-
 S.Mode	 Sound / Title	 Tv/Radio	 TV/Radio /
 Sleep	 Sleep / Timer	 FAV List	 Smart / List





Original	Replacement
 CH-	 CH- / Page-
 Play/Time Shift	 Play / Slow
 Pause	 Pause / Step / Freeze
 <</Guide	 << / Tune-
 >>/Aspect	 >> / Tune+
 Freeze	 Shift + Pause / Step /
 Stop/Index	 Stop / Hold
 <</Cancel	 << / Preset-
 >> /Sub.PG	 >> / Preset+
 Subtitle	 Subtitle / EQ
 Reveal	 Setup / OPT /
 Size	 Zoom / Size
 Hold	 Shift + Stop /
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat

Original	Replacement
 Cyan	 Blue / Prime Video / Random

