



Original	Replacement
	 Mute / Dimmer
	 Power
	 TV/Radio /
	 Guide / EPG / -/--
	 Fav / Marker / PC
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Menu / Home
	 0
	 Back / Return

Original	Replacement
	 Info / Angle
	 Vol+
	 OK
	 CH+ / Page+
	 Up
	 Left
	 Right
	 Vol-
	 Down
	 CH- / Page-
	 Exit / Cancel / Clear
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 << / Tune-
	 << / Preset-





Original		Replacement		Original		Replacement	
	Play / Pause		Play / Slow				
	>> / >>I		>> / Tune+				
	>> / >>I		>>I / Preset+				
	Library		Display / Media				
	Rec		Rec / Rec Mode				
	Stop		Stop / Hold				
	Text		Text / Goto				
	Personal Planner		Smart / List				
	Sub / Audio		Audio / Lang I/II				
	Sub / Audio		Subtitle / EQ				
	History		D.Menu / Top				
	PIP		Picture / Format				
	PIP Swap		Zoom / Size				
	PIP Position		Setup / OPT /				
	Sleep Timer		Sleep / Timer				

