
















































Original	Replacement	Original	Replacement
 Tv/Rad	 TV/Radio /	 A/V+	 AV / Input / RDS
 Input/Text	 Text / Goto	 Yellow	 Yellow / YouTube / Repeat
 1	 1	 FAV	 Fav / Marker / PC
 2	 2	 Blue/A-Z	 Blue / Prime Video / Random
 3	 3	 EPG	 Guide / EPG / -/-
 4	 4	 Info	 Info / Angle
 5	 5	 Menu	 Menu / Home
 6	 6	 Exit	 Exit / Cancel / Clear
 7	 7	 P-	 CH- / Page-
 8	 8	 P+	 CH+ / Page+
 9	 9	 Play	 Play / Slow
 0	 0	 Pause	 Pause / Step / Freeze
 Mute	 Mute / Dimmer	 <<	 << / Tune-
 Back	 Back / Return	 Stop	 Stop / Hold
 Red	 Red / Netflix / Search	 >>	 >> / Tune+
 Opt.	 Setup / OPT /	 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat	 List	 Smart / List





Original	Replacement
 I>/Slow	 Display / Media
 A-B	 Shift + Yellow / YouTube /
 Mark	 Shift + Fav / Marker / PC
 PIP	 Zoom / Size
 Jump	 Picture / Format
 Movie	 Eject / Surround
 Up	 Up
 Swap	 D.Menu / Top
 Down	 Down
 Right	 Right
 Left	 Left
 1 TV	 Shift + 1
 2 TV	 Shift + 2
 3 TV	 Shift + 3
 4 TV	 Shift + 4
 5 TV	 Shift + 5
 6 TV	 Shift + 6

Original	Replacement
 7 TV	 Shift + 7
 8 TV	 Shift + 8
 9 TV	 Shift + 9
 0 TV	 Shift + 0
 Mute TV	 Shift + Mute / Dimmer
 Input/Text TV	 Shift + Text /
 P+ TV	 Shift + CH+ /
 P- TV	 Shift + CH- /
 Vol-	 Vol-
 Vol- TV	 Shift + Vol-
 Sleep	 Sleep / Timer
 Power Tv	 Shift + Power
 Vol+ TV	 Shift + Vol+
 Power	 Power
 OK	 OK
 Vol+	 Vol+

