



Original	Replacement	Original	Replacement
Power	Power	Dev.List	Display / Media
Mute	Mute / Dimmer	EPG	Guide / EPG / -/-
1	1	Subtitle	Subtitle / EQ
2	2	Text	Text / Goto
3	3	Auto	Setup / OPT /
Lang	Audio / Lang I/II	Menu	Menu / Home
4	4	Zoom	Zoom / Size
5	5	Info	Info / Angle
6	6	Exit	Exit / Cancel / Clear
Game	Picture / Format	Up	Up
7	7	CH+	CH+ / Page+
8	8	Left	Left
9	9	Vol-	Vol-
Tv/Radio	TV/Radio /	Enter	OK
FAV	Fav / Marker / PC	Right	Right
0	0	Vol+	Vol+
Recall	Back / Return	CH-	CH- / Page-





Original	Replacement
 Down	 Down
 Filelist	 Smart / List
 Rec	 Rec / Rec Mode
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Red/FAV./Daily	 Red / Netflix / Search
 Green/Del./Weekl	 Green / APP / Repeat
 Yellow/Move/P.Inf	 Yellow / YouTube / Repeat
 Blue/Look/Timer	 Blue / Prime Video / Random

Original	Replacement

