











Original	Replacement
 Standby	 Power
 On	 AV / Input / RDS
 Keystone	 Audio / Lang I/II
 Up	 Up
 Menu/Help	 Menu / Home
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Back	 Fav / Marker / PC
 Forward	 >> / Tune+
 Break Timer	 Sleep / Timer
 Freeze	 Pause / Step / Freeze
 Vol+	 Vol+
 Picture Mode	 Picture / Format
 AV Mute	 Mute / Dimmer

Original	Replacement
 Vol-	 Vol-
 Input 1	 1
 Input 2	 2
 Auto Sync	 Guide / EPG / -/-
 Input 3	 3
 Input 4	 4
 Resize	 Zoom / Size

