


























































Original	Replacement
 POWER	 Power
 MUTE	 Mute
 P.MODE	 +  Shift + Format
 S.MODE	 Dual
 SLEEP	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/-	 Guide
 EXIT	 Exit

Original	Replacement
 INPUT	 AV
 MENU	 Menu
 RECALL	 Pre Ch
	 Left
	 Right
	 Up
	 Down
 ENTER	 Ok
 VOL+	 Vol +
 VOL-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 RED/DVD	 Red
 GREEN/DVD	 Green
 YELLOW/TITLE	 Yellow
 BLUE/LANG	 Blue
 DISPLAY	 Info





Original	Replacement
 ZOOM	 Shift + Eject
 PREVIEW	 TV/R
 SIZE	 Format
 STOP	 Stop
 PLAY/PAUSE	 Play
 II>/SLOW	 Pause
 <<	 <<
 >>	 >>
 I<<	 I<<
 >>I	 >>I
 S.MODE1	 Shift + Menu
 EJECT	 Eject
 AUTO	 Options
 A-B	 Shift + Play
 PROG	 Shift + Sleep
 GOTO	 Shift + Subt
 REPEAT	 Text

Original	Replacement
 P.MODE1	 Media
 SUBTITLE	 Subt
 ANGLE	 D. Menu

