

























| Original   | Replacement  |
|--|--|
|  Power  |  Power            |
|  1      |  1                |
|  2      |  2                |
|  3      |  3                |
|  PIP    |  Info / Angle     |
|  4      |  4                |
|  5      |  5                |
|  6      |  6                |
|  [ <> ] |  Picture / Format |
|  >     |  >>  / Preset+   |
|  7    |  7              |
|  8    |  8              |
|  9    |  9              |
|  ?    |  Smart / List   |
|   <   |   << / Preset-  |
|  0    |  0              |
|  Mute |  Mute / Dimmer  |







| Original   | Replacement  |
|--|--|
|  i/OSD          |  Display / Media          |
|  Z/Disc Menu    |  Menu / Home              |
|  Up             |  Up                       |
|  P+             |  CH+ / Page+              |
|  Left           |  Left                     |
|  Vol-           |  Vol-                     |
|  OK             |  OK                       |
|  Right          |  Right                    |
|  Vol+           |  Vol+                     |
|  TXT           |  Text / Goto             |
|  <<           |  << / Tune-             |
|  Down         |  Down                   |
|  P-           |  CH- / Page-            |
|  TV-G         |  Guide / EPG / -/-      |
|  >>           |  >> / Tune+             |
|  Red/Image/I> |  Red / Netflix / Search |
|  Green/Timer  |  Green / APP / Repeat   |







| Original  | Replacement   |
|---|---|
|  Power   |  Power             |
|  1       |  1                 |
|  2       |  2                 |
|  3       |  3                 |
|  Audio   |  Audio / Lang I/II |
|  4       |  4                 |
|  5       |  5                 |
|  6       |  6                 |
|  [ <> ]  |  Zoom / Size       |
|  >      |  >>  / Preset+    |
|  7     |  7               |
|  8     |  8               |
|  9     |  9               |
|  ?     |  Smart / List    |
|   <    |   << / Preset-   |
|  0     |  0               |
|  i/OSD |  Display / Media |
































| Original  | Replacement  |
|---|--|
|  Disc Menu     |  D.Menu / Top             |
|  Disc Menu     |  Menu / Home              |
|  Up            |  Up                       |
|  P+            |  CH+ / Page+              |
|  Left          |  Left                     |
|  Vol-          |  Vol-                     |
|  OK            |  OK                       |
|  Right         |  Right                    |
|  Vol+          |  Vol+                     |
|  TXT          |  Text / Goto             |
|  <<          |  << / Tune-             |
|  Down        |  Down                   |
|  P-          |  CH- / Page-            |
|  TV-G        |  Guide / EPG / -/-      |
|  >>          |  >> / Tune+             |
|  Red/Picture |  Picture / Format       |
|  Red/Picture |  Red / Netflix / Search |







| Original   | Replacement   |
|--|---|
|  Power  |  Power             |
|  1      |  1                 |
|  2      |  2                 |
|  3      |  3                 |
|  Audio  |  Audio / Lang I/II |
|  4      |  4                 |
|  5      |  5                 |
|  6      |  6                 |
|  [ <> ] |  Zoom / Size       |
|  >     |  >>  / Preset+    |
|  7    |  7               |
|  8    |  8               |
|  9    |  9               |
|  ?    |  Smart / List    |
|   <   |   << / Preset-   |
|  0    |  0               |
|  Mute |  Mute / Dimmer   |


| Original   | Replacement  |
|--|--|
|  i/OSD          |  Display / Media          |
|  Z/Disc Menu    |  Menu / Home              |
|  Up             |  Up                       |
|  P+             |  CH+ / Page+              |
|  Left           |  Left                     |
|  Vol-           |  Vol-                     |
|  OK             |  OK                       |
|  Right          |  Right                    |
|  Vol+           |  Vol+                     |
|  TXT           |  Text / Goto             |
|  <<           |  << / Tune-             |
|  Down         |  Down                   |
|  P-           |  CH- / Page-            |
|  TV-G         |  Guide / EPG / -/-      |
|  >>           |  >> / Tune+             |
|  Red/Image/I> |  Red / Netflix / Search |
|  Red/Image/I> |  Shift + Play / Slow    |







| Original  | Replacement   |
|---|---|
|  Power     |  Power             |
|  1         |  1                 |
|  2         |  2                 |
|  3         |  3                 |
|  PIP/Audio |  Audio / Lang I/II |
|  4         |  4                 |
|  5         |  5                 |
|  6         |  6                 |
|  [ <> ]    |  Zoom / Size       |
|  >        |  >>  / Preset+    |
|  7       |  7               |
|  8       |  8               |
|  9       |  9               |
|  ?       |  Smart / List    |
|   <      |   << / Preset-   |
|  0       |  0               |
|  i/OSD   |  Display / Media |

| Original   | Replacement  |
|--|--|
|  Z/Disc Menu    |  Menu / Home              |
|  P+             |  CH+ / Page+              |
|  Up             |  Up                       |
|  Left           |  Left                     |
|  Vol-           |  Vol-                     |
|  OK             |  OK                       |
|  Right          |  Right                    |
|  Vol+           |  Vol+                     |
|  TXT            |  Text / Goto              |
|  <<            |  << / Tune-              |
|  P-           |  CH- / Page-            |
|  Down         |  Down                   |
|  TV-G         |  Guide / EPG / -/-      |
|  >>           |  >> / Tune+             |
|  Red/Image/I> |  Picture / Format       |
|  Red/Image/I> |  Red / Netflix / Search |
|  Green/Timer  |  Green / APP / Repeat   |



