







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--	 +  <b>GUIDE</b>	Shift + Guide
	Repeat		Text
	Vol +		Vol +
	Vol -		Vol -
	Pic. Mode		Options
	S. Mode		Dual
	Source		AV
	CH +		Ch +
	CH -		Ch -
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	CH. Edit		Smart
	Menu		Menu
	Aspect		Format
	Sleep		Sleep
	Rec		Rec
	Rec Menu	 +  <b>REC MODE</b>	Shift + Rec
	Red		Red
	Green		Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue	 Blue		
 CH. Group	 3D		
 TV / Radio	 TV/R		
 I/II Audio	 Shift + Dual		
 Subtitle	 Subt		
 EPG	 Guide		
 Info	 Info		
 Play/Pause / Size	 Play		
 Play/Pause / Size	 Pause		
 Stop / Reveal	 Stop		
 I<< / Text (Page -)	 I<<		
 >>I / Index (Page +)	 >>I		
 << / Subpage (FAV -)	 <<		
 >> / Hold(Fav +)	 >>		

