









































































Original	Replacement	Original	Replacement
	Hold		Options
	Power		Power
	Sleep		Sleep
	TV		TV/R
	AV		AV
	Scart		Smart
	PC		Media
	Display		Info
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	Enter		Ok
	Menu		Menu
	TTX/MIX		Text
	Wide		Format
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	OK		Play
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Index		Back





	Original	Replacement	Original	Replacement
	Subtitle	 Subt		
	Size	 List		
	Subpage	 Dual		
	Reveal	 Exit		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		
	MPX	 Shift + Smart		

