























































Original		Replacement		Original		Replacement	
	Power		Power		4/VGA		4
	e		Smart / List		5/Component		5
	Aspect Ratio		Picture / Format		6/Video		6
	Freeze		Pause / Step / Freeze		PgDn		CH- / Page-
	Hide		Display / Media		7/S-Video		7
	Zoom		Zoom / Size		8/HDMI		8
	Resync		Back / Return		9/Wireless		9
	Source		AV / Input / RDS		Mute		Mute / Dimmer
	Keystone+		Up		0		0
	Left		Left				
	Menu		Menu / Home				
	Right		Right				
	Keystone-		Down				
	1		1				
	2		2				
	3		3				
	PgUp		CH+ / Page+				

