

















































Original		Replacement		Original		Replacement	
	Power		Power		Audio		Dual
	Mute		Mute		Menu		Menu
	Red		Red		Info		Info
	Green		Green		FAV		Pre Ch
	Yellow		Yellow		Exit		Exit
	Blue		Blue		Up		Up
	<<		<<		Down		Down
	>>		>>		Right		Right
	l<<		l<<		Left		Left
	>>l		>>l		OK		Ok
	Play		Play		Vol+		Vol +
	Pause		Pause		Vol-		Vol -
	Stop		Stop		CH+		Ch +
	Repeat	 + 	Shift + Text		CH-		Ch -
	Subtitle		Subt		1		1
	TTX		Text		2		2
	Recall		Back		3		3





Original		Replacement	
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Goto		Guide
	Tv/Radio		TV/R
	No name 1		Smart
	No name 2		Media

Original		Replacement	

