
















































































































































Original	Replacement	Original	Replacement
 Power	 Power	 Sleep	 Sleep / Timer
 Mute	 Mute / Dimmer	 Jump	 Display / Media
 Source	 AV / Input / RDS	 FAV.CH	 Fav / Marker / PC
 I/II/Audio	 Audio / Lang I/II	 OK	 OK
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Left	 Left
 4	 4	 Right	 Right
 5	 5	 Vol+	 Vol+
 6	 6	 Vol-	 Vol-
 7	 7	 PR-	 CH- / Page-
 8	 8	 PR+	 CH+ / Page+
 9	 9	 Red/D.Setup	 Red / Netflix / Search
 0	 0	 Green/Repeat	 Green / APP / Repeat
 Menu	 Menu / Home	 Yellow/Zoom	 Yellow / YouTube / Repeat
 Info	 Info / Angle	 Blue/Goto	 Blue / Prime Video / Random
 Exit	 Exit / Cancel / Clear	 [=+]/DTV/Radio	 TV/Radio /

Original	Replacement	Original	Replacement
 Power	 Mute / Dimmer	 Shift	 TV
 Mute	 DVD	 SLOW	 STEP-FREEZE
 Source	 SAT	 HOLD	 REC MODE
 I/II/Audio	 AUX	 PLAY	 PAUSE
 1	 PRESET-	 STOP	 PRESET+
 2	 TUNE-	 TUNE+	 EQ
 3	 LANG I/II	 SURROUND	 SOUND
 4	 AUDIO	 SUBTITLE	 FORMAT
 5	 SIZE	 TIMER	 PICTURE
 6	 SLEEP	 PROGRAM	 ZOOM
 7	 TV RADIO	 RDS	 TOP MENU
 8	 AV INPUT	 D.MENU	 OPT-TOOLS
 9	 HOME	 SETUP	 GOTO
 0	 ANGLE	 TEXT	 INFO
 Menu	 OK	 BACK	 RETURN
 Info	 CLEAR	 EXIT	 CANCEL
 Exit	 LIST	 SMART	 CH PAGE
	 MEDIA	 DISPLAY	 TV
	 VOL +	 VOL -	DVD
	CH PAGE -	CH PAGE +	CD - STB
	TV	DVD	TAPE
	DVD	CD - STB	TUNER
	CD - STB	AUX - HDD	USB
	AUX - HDD	USB	BLUETOOTH
	USB	HDMI - BAT	PC
	HDMI - BAT	GUIDE EPG	FAV MARKER
	GUIDE EPG	NETFLIX	APP
	NETFLIX	APP	YouTube
	APP	YouTube	Prime Video
	YouTube	Prime Video	RANDOM
	Prime Video	RANDOM	PROGRAM TV/RADIO
	RANDOM	TV/RADIO	TV/RADIO





Original	Replacement
 [=♦]/USB	 Setup / OPT /
 [=?]/PVR	 Smart / List
 [=i]/FAV.CH	 Zoom / Size
 Rec / Rec Mode	 Rec / Rec Mode
 Stop / Hold	 Stop / Hold
 Play / Slow	 Play / Slow
 << / Tune-	 << / Tune-
 >> / Tune+	 >> / Tune+
 I<< / Preset-	 I<< / Preset-
 >>I / Preset+	 >>I / Preset+
 DVD Menu / Top	 D.Menu / Top
 Text / Goto	 Text / Goto
 Subtitle / EQ	 Subtitle / EQ
 Guide / EPG / -/--	 Guide / EPG / -/--
 Eject / Surround	 Eject / Surround
 P.Mode / Picture / Format	 Picture / Format
 S.Mode / Sound / Title	 Sound / Title

Original	Replacement
 P.Size	 Shift + Zoom /

