







































































Original	Replacement	Original	Replacement
 Power	 Power	 YouTube	 Shift + Media
 Mute	 Mute	 Back	 Back
 1	 1	 Home	 Smart
 2	 2	 Exit	 Exit
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Red	 Red
 9	 9	 Green	 Green
 0	 0	 Yellow	 Yellow
 List	 List	 Blue	 Blue
 AD	 Shift + Subt	 [+]	 3D
 Source	 AV	 Info	 Info
 prime video	 Shift + Smart	 Vol+	 Vol +
 Netflix	 Media	 Vol-	 Vol -

Original	Replacement	Original	Replacement
 Power	 MUTE	 TV	 DVD
 Mute	 SHIFT	 SAT	 AUX
 1	 TV	 PLAY MODE	 REC MODE
 2	 MUTE	 Play	 Pause
 3	 BACK	 Stop	 FF
 4	 Smart	 Rewind	 Play/Pause
 5	 Exit	 FF	 Stop
 6	 Up	 DISC NAV	 SOUND
 7	 Down	 DUAL	 AD
 8	 Right	 LIST	 SETTINGS
 9	 Left	 SEARCH	 PICTURE
 0	 Ok	 SLEEP	 ECO
 List	 Red	 TV/R	 FORMAT
 AD	 Green	 E-MANUAL	 3D
 Source	 Yellow	 REPEAT	 TIMER
 prime video	 Blue	 D.MENU	 TEXT
 Netflix	 OK	 TOP MENU	 DISPLAY INFO
	 Red	 MENU	 INFO
	 Green	 UP	 OK
	 Yellow	 LEFT	 RIGHT
	 Blue	 DOWN	 OK
	 Red	 EXIT	 RETURN BACK
	Green	 VOL +	 HOME SMART
	Yellow	 VOL -	 APP MEDIA
	Blue	 1	 CH -
	Red	 2	 3
	Green	 4	 5
	Yellow	 5	 6
	Blue	 6	 7
	Red	 7	 8
	Green	8	9
	Yellow	9	FAV
	Blue	GUIDE	PRE-CH
	Red	A	B
	Green	C	D
	Yellow		
	Blue		



