
































































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Text		Text
	Audio		Dual
	Help		D. Menu
	Back		Back
	Subtitle		Subt
	Info		Info
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Exit		Exit
	Menu		Menu
	EPG		Guide
	Vol +		Vol +
	Vol -		Vol -
	CH + / Page +		Ch +
	CH - / Page -		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue





Original		Replacement		Original	Replacement
	Rec		Rec		
	Stop		Stop		
	Play / Pause		Play		
	Play / Pause		Pause		
	Timer		AV		
	I<		I<<		
	<<		<<		
	>>		>>		
	>I		>>I		
	V.Mode		Format		
	TV		TV/R		
	Radio		Shift + TV/R		
	Sleep		Sleep		

