
































































Original		Replacement		Original		Replacement	
<<		<< / Tune-		8		8	
>>		>> / Tune+		9		9	
I<<		I<< / Preset-		[≡?]/Source		Eject / Surround	
>>I		>>I / Preset+		0		0	
Play		Play / Slow		O)/I/II/Audio		Audio / Lang I/II	
Pause		Pause / Step / Freeze		Menu		Menu / Home	
Stop		Stop / Hold		Exit		Exit / Cancel / Clear	
	Power		Power			Up	
	[≡i]/Info		Info / Angle			Left	
	Mute		Mute / Dimmer			OK	
	1		1			Right	
	2		2			Down	
	3		3			CH+ / Page+	
	4		4			Display / Media	
	5		5			Vol+	
	6		6			CH- / Page-	
	7		7			Smart / List	





Original		Replacement		Original	Replacement
	Vol-		Vol-		
	♥		Fav / Marker / PC		
	Sleep		Sleep / Timer		
	EPG		Guide / EPG / -/--		
	Recall		Back / Return		
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	[≡]		Text / Goto		
	[≡+]/Still		Zoom / Size		
	Radio		TV/Radio /		
	[≡◆]/[++]		Picture / Format		
	[≡x]		Setup / OPT /		
	[≡o]/Subtitle		Subtitle / EQ		
	DMP		D.Menu / Top		
	Rec		Rec / Rec Mode		

