







































































Original	Replacement	Original	Replacement
 Power	 Power	 16:9	 16:9
 Sleep	 Sleep	 Lang	 Lang
 Mute	 Mute	 RCL	 RCL
 Timer	 AV	 FAV	 FAV
 EPI	 Guide	 Page+ / Timeshift	 Page+ / Timeshift
 SUBTL	 Subt	 Page- / V-Format	 Page- / V-Format
 Audio	 Shift + Dual	 Page- / V-Format	 Page- / V-Format
 1	 1	 Up / CH+	 Up
 2	 2	 Up / CH+	 Ch +
 3	 3	 Down / CH-	 Down
 4	 4	 Down / CH-	 Ch -
 5	 5	 Right / Vol+	 Right
 6	 6	 Right / Vol+	 Vol +
 7	 7	 Left / Vol-	 Left
 8	 8	 Left / Vol-	 Vol -
 9	 9	 OK	 Ok
 0	 0	 Menu	 Menu

Original	Replacement	Original	Replacement
 16:9	 16:9	 Format	 Format
 Lang	 Lang	 Dual	 Dual
 RCL	 RCL	 Back	 Back
 FAV	 FAV	 Pre Ch	 Pre Ch
 Page+ / Timeshift	 Page+ / Timeshift	 Shift + Ch +	 Shift + Ch +
 Page- / V-Format	 Page- / V-Format	 Shift + Ch -	 Shift + Ch -
 Page- / V-Format	 Page- / V-Format	 Shift + Format	 Shift + Format
 Up / CH+	 Up / CH+	 Up	 Up
 Up / CH+	 Up / CH+	 Ch +	 Ch +
 Down / CH-	 Down / CH-	 Down	 Down
 Down / CH-	 Down / CH-	 Ch -	 Ch -
 Right / Vol+	 Right / Vol+	 Right	 Right
 Right / Vol+	 Right / Vol+	 Vol +	 Vol +
 Left / Vol-	 Left / Vol-	 Left	 Left
 Left / Vol-	 Left / Vol-	 Vol -	 Vol -
 OK	 OK	 Ok	 Ok
 Menu	 Menu	 Menu	 Menu





Original	Replacement
 Info	 Info
 TXT	 Text
 Exit	 Exit
 Red / SAT	 Red
 Green / Zoom	 Green
 Green / Zoom	 Eject
 Yellow / Pause	 Yellow
 Yellow / Pause	 Shift + Pause
 Blue / TV/Radio	 Blue
 Blue / TV/Radio	 TV/R
	
	
 Play / Pause	 Play
 Play / Pause	 Pause
 Stop	 Stop
 <<	 <<
 >>	 >>

Original	Replacement
 Slow	 Shift + Play
 Rec	 Rec
 Media	 Media
 Game	 Smart
 PVR	 Shift + Smart
 HDD	 Shift + Media

