















































































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Rec List	 Shift + Rec / Rec Mode
 CH/List	 Smart / List
 Subtitle	 Subtitle / EQ
 Repeat	 Shift + Green / APP /
 Rec	 Rec / Rec Mode
 Stop	 Stop / Hold
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 <<	 << / Tune-
 >>	 >> / Tune+
 Source	 AV / Input / RDS
 Up	 Up
 Display	 Display / Media

Original	Replacement
 Left	 Left
 Ok	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back / Return





Original	Replacement
	 Fav / Marker / PC
	 Vol+
	 Picture / Format
	 Guide / EPG / -/--
	 CH+ / Page+
	 Vol-
	 Sound / Title
	 Sleep / Timer
	 CH- / Page-
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Text / Goto
	 Shift + Exit / Cancel / Clear
	 Setup / OPT /
	 Audio / Lang I/II

Original	Replacement
	 Shift + Stop /
	 Zoom / Size
	 Eject / Surround
	 Info / Angle

