



Original	Replacement
	Mute / Dimmer
	Up
	Power
	Left
	OK
	Right
	Menu / Home
	Down
	Info / Angle
	1
	2
	3
	4
	5
	6
	7
	8

Original	Replacement
	9
	Smart / List
	0
	CH+ / Page+
	Back / Return
	Vol-
	Vol+
	CH- / Page-
	Shift + Back / Return
	TV/Radio /
	Fav / Marker / PC
	AV / Input / RDS
	Shift + CH+ /
	Red / Netflix / Search
	Green / APP / Repeat
	Shift + CH- /
	Yellow / YouTube / Repeat





Original		Replacement		Original	Replacement
	Blue		Blue / Prime Video / Random		
	Screen		Picture / Format		
	Lang		Audio / Lang I/II		
	Subtitle		Subtitle / EQ		
	Sleep		Sleep / Timer		
	[ ≡ ]		Text / Goto		
	[ ≡ X ]		Exit / Cancel / Clear		
	EPG		Guide / EPG / -/--		
	[ ■ ][ ■■ ]		Display / Media		

