




















































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[≡]/TXT		Text
	[+]/Display		Info
	Tv/DVB-T		Smart
	[]/Line		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	PRE		Pre Ch
	Up/P+		Up
	Down/P-		Down
	Right/Vol+		Right
	Left/Vol-		Left
	[II]/Tv Menu		Menu
	-IXI-/Exit		Exit
	Timer/Sleep		Shift + Power
	-I/I-/P.STD		Shift + Format
	-I/I-/S.STD		Shift + Dual
	[<>]/P.Size		Format
	Open/Close		Eject
	Rec		Rec





Original	Replacement
	Stop
	Play
	Pause
	<<
	<<
	I<<
	>>
	>>
	I>>
	Red
	Green
	Yellow
	Blue
	SHIFT + 3D
	SHIFT + AV
	SHIFT + TV/R
	SHIFT + Subt
	SHIFT + Text
	SHIFT + Info

Original	Replacement
	Dual
	Subt
	Options
	TV/R
	SHIFT + Ch -
	SHIFT + Ch +
	Guide
	3D
	Back
	AV
	Ok

