



| Original   | Replacement   | Original   | Replacement   |
|--|---|--|---|
|  Power    |  Power         |  7              |  7               |
|  Mute     |  Mute          |  8              |  8               |
|  Audio    |  Dual          |  9              |  9               |
|  TV / STB |  Shift + TV/R |  0              |  0               |
|  TV / R   |  TV/R          |  PGUP           |  Vol +           |
|  Sleep    |  Sleep         |  PGDN           |  Vol -           |
|  SUB      |  Subt          |  SAT            |  Shift + AV      |
|  TXT      |  Text          |  FAV +          |  Ch +            |
|  Multi    |  Smart         |  FAV -          |  Ch -            |
|  P / N    |  Shift + 1    |  EPG            |  Guide           |
|  Recall  |  Pre Ch       |  Fav           |  Shift + Pre Ch |
|  1      |  1           |  Up / CH+     |  Up            |
|  2      |  2           |  Right / Vol+ |  Right         |
|  3      |  3           |  Down / CH-   |  Down          |
|  4      |  4           |  Left / Vol-  |  Left          |
|  5      |  5           |  OK           |  Ok            |
|  6      |  6           |  Menu         |  Menu          |



