




















Original	Replacement
	Power
	Mute
	Nicam/A2
	Aspect
	PMode
	SMode
	1
	2
	3
	4
	5
	6
	7
	8
	9
	-/--
	0

Original	Replacement
	Recall
	Display
	Freeze
	Auto/Goto
	Red
	Green
	Yellow
	Blue
	Sleep
	Source
	Up
	Left
	Enter
	Right
	Down
	Menu
	Exit

	Back / Return
	Display / Media
	Shift + Pause / Step /
	Shift + Text /
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Sleep / Timer
	AV / Input / RDS
	Up
	Left
	OK
	Right
	Down
	Menu / Home
	Exit / Cancel / Clear



