







































Original	Replacement
 Power	 Power
 SAT	 Smart / List
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back / Return
 Tv/Radio	 TV/Radio /
 Menu	 Menu / Home
 EPG	 Guide / EPG / -/--

Original	Replacement
 FAV	 Fav / Marker / PC
 Up	 Up
 Down	 Down
 OK	 OK
 Right	 Right
 Left	 Left
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 Vol-	 Vol-
 Page+	 CH+ / Page+
 Page-	 CH- / Page-
 Audio	 Red / Netflix / Search
 Pause	 Green / APP / Repeat
 Zoom	 Yellow / YouTube / Repeat
 i	 Blue / Prime Video / Random
 F1	 Picture / Format
 F2	 Zoom / Size





Original	Replacement
F3	TIMER SLEEP Sleep / Timer
TXT	GOTO TEXT Text / Goto

Original	Replacement

