








































































Original	Replacement	Original	Replacement
	Power		Power
	Energy Saving		3D
	AV Mode		Shift + AV
	Input		AV
	TV / Rad		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Q.View		Pre Ch
	Vol +		Vol +
	Vol -		Vol -
	Fav Mark		Shift + Pre Ch
	Ratio		Format
	Mute		Mute
	P + / Page +		Ch +
	P - / Page -		Ch -
	Menu		Menu
	Guide		Guide
	Q.Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Back		Back
	Info		Info





Original	Replacement	Original	Replacement
 Exit	 Exit		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 T.Opt	 Options		
 Subtitle	 Subt		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 <<<	 <<<		
 <<<	 I<<<		
 >>>	 >>>		
 >>>	 >>>I		
 Simplink	 Smart		

