




























































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	Energy Saving		Shift + 3D		Vol-		Vol -
	AV Mode		Shift + AV		FAV		Pre Ch
	Input		AV		3D		3D
	Tv/Radio		TV/R		Mute		Mute
	1		1		P+		Ch +
	2		2		P-		Ch -
	3		3		Guide		Guide
	4		4		Home		Smart
	5		5		Q Menu		Menu
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Down		Down
	List		List		Back		Back
	Q.View		Media		Info		Info



