





































| Original  | Replacement | Original  | Replacement                 |
|---|-------------|---|-----------------------------|
|    | Power       |    | Power                       |
|    | 1           |    | 1                           |
|    | 2           |    | 2                           |
|    | 3           |    | 3                           |
|    | 4           |    | 4                           |
|    | 5           |    | 5                           |
|    | 6           |    | 6                           |
|    | 7           |    | 7                           |
|    | 8           |    | 8                           |
|    | 9           |    | 9                           |
|   | FAV         |   | Fav / Marker / PC           |
|  | 0           |  | 0                           |
|  | TXT         |  | Text / Goto                 |
|  | Red         |  | Red / Netflix / Search      |
|  | Green       |  | Green / APP / Repeat        |
|  | Yellow      |  | Yellow / YouTube / Repeat   |
|  | Blue        |  | Blue / Prime Video / Random |

| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|    | Exit        |    | Exit / Cancel / Clear |
|    | ?           |    | D.Menu / Top          |
|    | @           |    | Smart / List          |
|    | Menu        |    | Menu / Home           |
|    | Up          |    | Up                    |
|    | Back        |    | Back / Return         |
|    | Left        |    | Left                  |
|    | OK          |    | OK                    |
|    | Right       |    | Right                 |
|    | Tools       |    | Setup / OPT /         |
|   | Down        |   | Down                  |
|  | Guide       |  | Guide / EPG / -/--    |
|  | Vol+        |  | Vol+                  |
|  | Source      |  | AV / Input / RDS      |
|  | P+          |  | CH+ / Page+           |
|  | Vol-        |  | Vol-                  |
|  | Mute        |  | Mute / Dimmer         |





| Original   | Replacement   | Original | Replacement |
|--|---|----------|-------------|
|  P-         |  CH- / Page-               |          |             |
|  I<         |  I<< / Preset-             |          |             |
|  >I         |  >>I / Preset+             |          |             |
|  <<         |  << / Tune-                |          |             |
|  >>         |  >> / Tune+                |          |             |
|  Rec        |  Rec / Rec Mode            |          |             |
|  Play       |  Play / Slow               |          |             |
|  Pause      |  Pause / Step / Freeze     |          |             |
|  Stop       |  Stop / Hold               |          |             |
|  3D        |  Picture / Format         |          |             |
|  ..O      |  Zoom / Size             |          |             |
|  [...].   |  Subtitle / EQ           |          |             |
|  Netflix  |  Shift + Red / Netflix / |          |             |
|  My Media |  Display / Media         |          |             |
|  |   |          |             |
|  |   |          |             |
|  |   |          |             |

