






























































Original		Replacement		Original		Replacement	
	Power		Power		Guide		Guide
	Micro		Options		▲		Ch +
	Up		Up		▼		Ch -
	Down		Down		1		1
	Right		Right		2		2
	Left		Left		3		3
	OK		Ok		4		4
	Back		Back		5		5
	Home		Smart		6		6
	=		Menu		7		7
	Play		Play		8		8
	<<		<<		9		9
	Pause		Pause		0		0
	>>		>>		Subt		Subt
	Vol+		Vol +		TXT		Text
	Vol-		Vol -		prime video		TV/R
	Mute		Mute		Netflix		Media



