







































































Original	Replacement	Original	Replacement
 Power	 Power	 CH.List	 List
 Info	 Info	 [=]	 Menu
 Input	 AV	 Smart Colours	 Smart
 [++]	 Media	 Back	 Back
 []1	 Format	 Play	 Play
 []2	 3D	 Pause	 Pause
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Vol+	 Vol +
 7	 7	 Vol-	 Vol -
 8	 8	 Mute	 Mute
 9	 9	 Home	 Shift + Smart
 0	 0	 CH+	 Ch +
 Guide	 Guide	 CH-	 Ch -





Original	Replacement	Original	Replacement
TXT	Text		
Micro	TV/R		
Sub.	Subt		
Netflix	Green		
prime video	Blue		
YouTube	Red		
Rakuten Tv	Yellow		

