






















































































Original	Replacement	Original	Replacement
 Power	 Power		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Vol+	 Vol+		
 CH+	 CH+ / Page+		
 Vol-	 Vol-		
 Mute	 Mute / Dimmer		
 CH-	 CH- / Page-		
 Source	 AV / Input / RDS		







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu / Home
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Red		Red / Netflix / Search
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	i		Info / Angle
	CH+		CH+ / Page+
	CH-		CH- / Page-





Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu / Home
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Media		Display / Media
	Up		Up
	Guide		Guide / EPG / -/-
	Left		Left
	OK/List		OK
	OK/List	 + 	Shift + Smart / List
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Last		Back / Return
	Vol+		Vol+
	Info		Info / Angle



























































Original	Replacement
CH+	CH+ / Page+
Vol-	Vol-
Mute	Mute / Dimmer
CH-	CH- / Page-
I>	Shift + Play /
I<<	I<< / Preset-
>>I	>>I / Preset+
?	D.Menu / Top
Audio	Audio / Lang I/II
[...]	Subtitle / EQ
[+≡]	Sound / Title
[≡I≡]	Smart / List
OPT+	Setup / OPT /
Edit	Fav / Marker / PC
Teletext	Text / Goto
Tv/Radio	TV/Radio /
Sleep	Sleep / Timer

Original	Replacement
Source	AV / Input / RDS
Wide	Zoom / Size
V-Format	Picture / Format





Original	Replacement	Original	Replacement
 Power	 Power	 OK/List	 Smart / List
 1	 1	 Right	 Right
 2	 2	 Exit	 Exit / Cancel / Clear
 3	 3	 Down	 Down
 4	 4	 Vol+	 Vol+
 5	 5	 Info	 Info / Angle
 7	 7	 CH+	 CH+ / Page+
 8	 8	 Vol-	 Vol-
 9	 9	 Mute	 Mute / Dimmer
 0	 0	 CH-	 CH- / Page-
 Menu	 Menu / Home		
 <<	 << / Tune-		
 >>	 >> / Tune+		
 Up	 Up		
 Guide	 Guide / EPG / -/--		
 Left	 Left		
 OK/List	 OK		

