


































Original	Replacement
 Power	 Power
 TV	 Picture / Format
 Back	 Back / Return
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Ok	 OK
 Right	 Right
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Stop	 Stop / Hold
 Smart Tv	 Smart / List
 Skip Prev.	 I<< / Preset-
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Skip Next	 >>I / Preset+
 Ch+	 CH+ / Page+

Original	Replacement
 Vol-	 Vol-
 Vol+	 Vol+
 Ch-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue/00/Lang.	 Blue / Prime Video / Random
 Mute	 Mute / Dimmer
 Rec	 Rec / Rec Mode
 Source	 AV / Input / RDS
 Option	 Setup / OPT /
 Subt.	 Subtitle / EQ
 IPTV	 Display / Media
 Eco / Search	 Fav / Marker / PC
 Guide-Popup	 Guide / EPG / -/-
 Ch.List	 Shift + Smart / List
 Info	 Info / Angle





Original		Replacement	
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Disc Menu		D.Menu / Top
	0		0
	Text / Media		Text / Goto
	Sound		Sound / Title
	 ↑ ↓ → ←		Zoom / Size
	Repeat	 + 	Shift + Green / APP /

Original		Replacement	





Original	Replacement	Original	Replacement
	Power		Power
	(•J)		TV/Radio /
	Back		Back / Return
	Menu		Menu / Home
	Up		Up
	Left		Left
	Ok		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Stop		Stop / Hold
	Smart Tv		Smart / List
	Skip Prev.		I<< / Preset-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Skip Next		>>I / Preset+
	Ch+		CH+ / Page+
	Vol-		Vol-
	Vol+		Vol+
	Ch-		CH- / Page-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue/00/Lang.		Blue / Prime Video / Random
	Mute		Mute / Dimmer
	Rec		Rec / Rec Mode
	Source		AV / Input / RDS
	Option		Setup / OPT /
	Subt.		Subtitle / EQ
	Iptv		Display / Media
	Eco/Search		Fav / Marker / PC
	Guide/ Popup		Guide / EPG / -/-
	Ch.List		Shift + Smart / List
	Info		Info / Angle





Original	Replacement
1	TV 1
2	DVD 2
3 DEF	CD - STB 3
4 DISC	VIDEO 4
5 INCL	TAPE 5
6 MIND	TUNER 6
7 POPS	AUX - HDD 7
8 TUV	USB 8
9 NXYZ	BLUETOOTH 9
DISC MENU	TOP MENU D.MENU
0	HDMI - BAT 0
TEXT MEDIA CENTER	GOTO TEXT
SOUND	TITLE SOUND
Repeat	SIZE ZOOM
	SHIFT + APP REPEAT

Original	Replacement

