















































































Original	Replacement
	 Power
	 Smart
	 AV
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Pre Ch
	 Info
	 Shift + Pre Ch
	 Shift + Format

Original	Replacement
	 Shift + Dual
	 Vol +
	 Vol -
	 Mute
	 Ch +
	 Ch -
	 Menu
	 Guide
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Dual
	 Format
	 Eject
	 Exit





Original	Replacement	Original	Replacement
 Radio	 TV/R	 Mix/CH Down	 Shift + Ch -
 Next	 >>I	 Subcode/Source	 Shift + AV
 Lang	 List	 Index/Position	 Media
 Subtitle	 Subt	 Hold/Sleep	 Sleep
 Back	 Back		
 Forward	 >>		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 Size/PIP	 3D		
 Reveal/Swap	 Options		
 Cancel/CH Up	 Shift + Ch +		

Original	Replacement	Original	Replacement
 Radio	 TV/R	 Mix/CH Down	 Shift + Ch -
 Next	 >>I	 Subcode/Source	 Shift + AV
 Lang	 List	 Index/Position	 Media
 Subtitle	 Subt	 Hold/Sleep	 Sleep
 Back	 Back		
 Forward	 >>		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 Size/PIP	 3D		
 Reveal/Swap	 Options		
 Cancel/CH Up	 Shift + Ch +		

