

















































Original		Replacement		Original		Replacement	
	Power		Power		Green / Sleep		Sleep
	Mute		Mute		Yellow / Input		Yellow
	1		1		Yellow / Input		AV
	2		2		Blue / Normal		Blue
	3		3		Index- / [≡□]		I<<
	4		4		Index+ / [≡□]		>>I
	5		5		Up / PR/TRK+ / Page+		Up
	6		6		Up / PR/TRK+ / Page+		Ch +
	7		7		Down / PR/TRK- / Page-		Down
	8		8		Down / PR/TRK- / Page-		Ch -
	9		9		Right / Vol+		Right
	0 / ATK		0		Right / Vol+		Vol +
	C-Reset		Pre Ch		Left / Vol-		Left
	C-0 Stop		Guide		Left / Vol-		Vol -
	Red / Clear		Red		Menu		Menu
	Red / Clear		Exit		Menu		Ok
	Green / Sleep		Green		Rec / OTR		Rec





Original	Replacement	Original	Replacement
 Recall / [= ?]	 Back		
 Pause	 Pause		
 Stop	 Stop		
 [=]	 Text		
 << / [≡]	 <<		
 >> / [≡●]	 >>		
 Play / [≡⇅]	 Play		
 SV/V+ / [≡X]	 Smart		

