



| Original | | Replacement | | Original | | Replacement | |
|----------|--------|-------------|-------|----------|--------|-------------|--------|
| | Power | | Power | | 5 | | 5 |
| | i | | Info | | 6 | | 6 |
| | Mute | | Mute | | 7 | | 7 |
| | Av/TV | | AV | | 8 | | 8 |
| | EPG | | Guide | | 9 | | 9 |
| | M/Menu | | Menu | | 0 | | 0 |
| | Back | | Back | | Vol+ | | Vol + |
| | Home | | Smart | | Vol- | | Vol - |
| | OK | | Ok | | P+ | | Ch + |
| | Up | | Up | | P- | | Ch - |
| | Down | | Down | | Red | | Red |
| | Right | | Right | | Green | | Green |
| | Left | | Left | | Yellow | | Yellow |
| | 1 | | 1 | | Blue | | Blue |
| | 2 | | 2 | | Rec | | Rec |
| | 3 | | 3 | | Stop | | Stop |
| | 4 | | 4 | | Play | | Play |



