







































































Original	Replacement	Original	Replacement
 Power	 Power	 AV	 AV / Input / RDS
 Top Menu	 D.Menu / Top	 Vol+	 Vol+
 Guide	 Guide / EPG / -/--	 P-	 CH- / Page-
 Up	 Up	 Mute	 Mute / Dimmer
 Left	 Left	 Vol-	 Vol-
 OK	 OK	 1	 1
 Right	 Right	 2	 2
 Menu	 Menu / Home	 3	 3
 Down	 Down	 4	 4
 Back	 Back / Return	 5	 5
 Exit	 Exit / Cancel / Clear	 6	 6
 Zoom	 Zoom / Size	 7	 7
 Red	 Red / Netflix / Search	 8	 8
 Green	 Green / APP / Repeat	 9	 9
 Yellow	 Yellow / YouTube / Repeat	 i	 Info / Angle
 Blue	 Blue / Prime Video / Random	 0	 0
 P+	 CH+ / Page+	 [≡]	 Text / Goto



