







































































Original	Replacement	Original	Replacement
 Standby	 Power	 Open/Close	 Eject
 DVD	 Smart	 Tv/Video	 TV/R
 HDD	 Media	 Guide	 Guide
 1	 1	 Info	 Info
 2	 2	 Enter	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Menu	 Menu
 8	 8	 Top Menu	 Shift + Menu
 9	 9	 Cancel	 Exit
 0	 0	 Navigation	 List
 Vol+ Tv	 Vol +	 Return	 Back
 Vol- Tv	 Vol -	 Edit	 Text
 PR+	 Ch +	 Prog	 Sleep
 PR-	 Ch -	 Day(-)	 I<<





Original		Replacement		Original		Replacement	
	>>I/Day(+)		>>I		Rec		Rec
	Play		Play		Angle/Live Check		D. Menu
	Stop/Clear		Stop		Standby Tv		Shift + Power
	Pause		Pause		Tv/Video Tv		Shift + TV/R
	<</Slow-		<<		Live		3D
	>>/Slow+		>>		?/Help		Pre Ch
	Memo/Mark		AV		PR+ Tv		Shift + Ch +
	Red/Display		Red		PR- Tv		Shift + Ch -
	Green/On		Green		Prog Tv		Shift + Sleep
	Yellow/Recall		Yellow		1 Tv		Shift + 1
	Blue/→		Blue		2 Tv		Shift + 2
	Audio		Dual		3 Tv		Shift + 3
	Subtitle/VPS/PDC/Timer		Subt		4 Tv		Shift + 4
	Format/Output		Format		5 Tv		Shift + 5
	Dubbing		Shift + Options		6 Tv		Shift + 6
	Setup		Options		7 Tv		Shift + 7
	Rec		Shift + Rec		8 Tv		Shift + 8

Mode/Remain







Original		Replacement		Original		Replacement	
	9 Tv	 + 	Shift + 9				
	0 Tv	 + 	Shift + 0				
	Cancel Tv	 + 	Shift + Exit				
	Tv Mute		Mute				
	Guide Tv	 + 	Shift + Guide				

